


All Geofire door holders are supplied with a keeper plate as standard but an alternative design can be supplied to suit the installation. All keeper plates are also available as spare parts.

The chain keeper can be used where the door will not open back to the wall. The chain keeper will bridge the gap from the open door to where the magnet is mounted.

Adjustable and low profile keeper plates are also available, see the keeper plates datasheet.

Item	Holding force	Adjustment	Order code
Chain keeper	200N	n/a	2-31-0308-Z082
Chain keeper with rubber O ring	200N	n/a	2-31-0308-Z083


CHAIN KEEPER



CHAIN KEEPER FITTING



Chain perpendicular/90° to the magnet face



Chain at an angle to magnet face